
HERO 5

LET'S GET STARTED

Learn more at gopro.com/your hero5



Open the battery door.

NOTICE

The camera is not waterproof when the doors are open.

Insert a microSD[™] card (sold separately) + battery.

POWER ON



Power on the camera.

Take the camera tour.







Open the side door.

Charge the battery.



Select the desired camera mode with the touch display or Mode button.

VOICE CONTROL





1. Swipe down, then tap Preferences > On Camera Voice Control.

2. Select a language. For English and Spanish, be sure to choose your dialect. 3. Tap On.

4. Say a command:

- GoPro start recording
- · GoPro stop recording
- · GoPro take a photo

To see all of the commands, go to Preferences > List of Commands.




Press the Shutter button to start and stop recording.

TIP

If you are recording video or time lapse, stop recording before issuing a new command.

CAMERA MOUNTING



Apply an adhesive mount to a clean surface at room temperature. Insert the camera into the mounting frame.

Click the mounting buckle into the adhesive mount. APPS

Capture and create stunning videos. Our mobile and desktop apps make it easy.



CAPTURE

Live preview, playback + full camera control.



QUIK[™] Awesome edits made easy.





QUIK | DESKTOP

Import and enjoy your footage, and create awesome videos with just a few clicks.

Download at gopro.com/apps

UPDATE YOUR GOPRO

Connect to the Capture app or Quik desktop app to check for updates and get the latest camera features.

After use in sand, dirt or salt water, rinse the camera in fresh water.

TIP



ACCESS + SHARE FROM ANYWHERE

With an optional GoPro Plus subscription, your HERO5 can auto upload photos and videos to the cloud for easy access, editing and sharing on your phone.



Start your free trial at gopro.com/plus



GOPRO AWARDS

Submit your best photos and videos to GoPro. Our favorites receive cash awards.

Submit at gopro.com/awards



See the list of country certifications in Important Product + Safety Instructions.